

## PEDAL

Stop	GERMAN	BAROQUE	ROMANTIC	SYMPHONIC
<b>Subbass 16'</b>	Subbass 16 A	Subbass 16 B	Soubasse 16	Sub Bass 16
<b>Prinzival 8'</b>	Prinzival 8A	Oktavbass 8	FlutePrinci8	Octave 8
<b>Spitzflöte 8'</b>	Spitzflöte 8	Gedackt 8 A	Bourdon 8 D	BassFlute 8A
<b>Choral- bass 4'</b>	Choralbass4A	Choralbass4H	Flute 4 I	Choralbass4C
<b>Bombarde 16'</b>	Bombarde 16A	Posaune 16 B	Bombarde 16B	Bombarde 16D
<b>Holz- trompete 8'</b>	Hlztrompete8	Trompete 8A	Trompette 8C	Trumpet 8 C

## HAUPTWERK

Stop	GERMAN	BAROQUE	ROMANTIC	SYMPHONIC
<b>Prinzival 8'</b>	Prinzival 8A	Prinzival 8D	Montre 8	1StDiapason8
<b>Gemshorn 8'</b>	Gemshorn 8	Hohlflöte 8A	FlûteHarmon8	FlautoTrave8
<b>Oktave 4'</b>	Oktave 4 A	Oktave 4 D	Octave 4 A	Octave 4 C
<b>Nacht- horn 4'</b>	Nachthorn 4	Spitzflöte4C	FlûteFuseau4	RohrFlute 4
<b>Quinte 2 2/3'</b>	Quinte2 2/3A	Quinte2 2/3C	Quinte2 2/3B	Twelfth22/3B
<b>Super- oktave 2'</b>	Superoktav2A	Superoktav2B	Doublette 2A	Fifteenth 2A
<b>Mixtur IV</b>	Mixtur IV A	Mixtur V B	FournitureIV	FournitureIV
<b>Trompete 8'</b>	Trompete 8 A	Trompete 8 C	Trompette 8B	Trumpet 8 B

## SCHWELLWERK

Stop	GERMAN	BAROQUE	ROMANTIC	SYMPHONIC
<b>Rohrflöte 8'</b>	Rohrflöte 8A	Rohrgedackt8	FlûteTraver8	ChimneyFlt8B
<b>Spitz- gamba 8'</b>	Spitzgamba 8	ViolaDiGam8A	VioleDeGam8A	Gamba 8 A
<b>Vox Coelestis 8'</b>	VoxCoelest8A	VoxCeleste8H	VoixCeleste8	GmbCeleste8D
<b>Holzflöte 4'</b>	Holzflöte 4	WaldFlute 4A	FlûteChemin4	HarmFlute 4B
<b>Nasard 2 2/3'</b>	Nasard2 2/3A	Nasard2 2/3C	NasardH2 2/3	Nazard2 2/3A
<b>Offenflöte 2'</b>	Offenflöte 2	Blockflöte2B	Octavin 2	BlockFlute 2
<b>Terz 1 3/5'</b>	Terz 1 3/5 A	Terz 1 3/5 B	TierceH1 3/5	Tiercel 3/5B
<b>Zymbel III</b>	Zymbel III	Scharf III	P.Jeu Harmon	PleinJeu IV
<b>Schalmey 8'</b>	Schalmey 8	Oboe 8 B	BassonHautb8	Oboe 8 C