

SYNTH-8 PACKS

Welcome!

Synth-8 Packs contain some programs and synth presets specially developed with the new Synth-8 module for the Legend '70s Stage Piano.

All program and synth preset files included in the pack can be loaded into the instrument using the "Legend '70s Editor" application, available for Windows, MacOS and iOS. Programs can also be loaded directly from the instrument with a USB flash drive.

The "Legend '70s Editor" application allows you to control all the parameters and functions of Synth-8 in real time and make the modification of new presets as simple as having a complete control panel. Thanks to the simple and intuitive interface of the "Legend '70s Editor", the control of Synth-8 will be extremely comfortable and fast, that's why it is strongly recommended for configuring this module. "Legend '70s Editor" is completely free and can be downloaded from the website www.viscountinstruments.com.



How to load program or synth preset files with the "Legend '70s Editor"

- 1 – Download and install the "Legend '70s Editor" to your computer (www.viscountinstruments.com).
- 2 – Connect usb cable to the instrument and press [CONNECT] button on the application.
- 3 – Click the [PROGRAM] button on the top menu of the application and select the program location you want to replace from the program list.
- 4 – Click [LOAD] button to load the program file .L7P in the current location or click [LOAD PRESET] button to load the synth preset file .L7SP into the current program.

For further information please refer to the "Legend '70s Editor" User Guide, available [Here](#)

How to load program files with a USB flash drive

- 1 – From your computer, copy all the program files .L7P into the <Legend'70s\Program> folder of the USB flash drive.
- 2 – Insert the USB flash drive in the USB [TO DEVICE] connector of the instrument.
- 3 – From the instrument, select the program you want to replace. Enter UTILITY page under the SYSTEM menu and move to the Load functions. Select “Load Program” function and press the data entry dial.
- 4 – Scroll through the program files on the USB flash drive with the dial data entry and select the program you want to load. Press enter to confirm.

For further information please refer to the Legend '70s User Manual, available [Here](#)